

LSU Telecommunication Notes to Designer

Telecom Room:

Grounding o Grounding wire (6 AWG green)

- o Grounding Bus Bars
- o Rack must be grounded to Bus Bar
- o Building Protectors must be grounded to Bus Bar

Building Protectors

- o Must be stub-in-stub-out type.
- o
